



Wymiary kołnierza PAM

IEC	D	F	G	P	M	N	S	T
63B5	11	4	12.8	140	115	95	9	5
71B5	14	5	16.3	160	130	110	9	5
71B14	14	5	16.3	105	85	70	7	5
80B5	19	6	21.8	200	165	130	11	5
80B14	19	6	21.8	120	100	80	7	5
90B5	24	8	27.3	200	165	130	11	5
90B14	24	8	27.3	140	115	95	9	5

Wymiary łap przekładni DRC01

Foot Code	U	V	V ₁	V ₂	V ₃	W	X	X ₁	Y	Z
B02	18	107.5	60	-	130	11	136	155	95	17
M02	25	85	-	110	120	9	112	145	75	15
M01	18	80	-	110	120	9	118	145	75	15
B01	18	87	50	110	-	9	118	130	85	15

i	63B5	71B5 71B14	80B5 80B14	90B5 90B14
53.33				
45.89				
40.10				
35.47				
28.50				
23.56				
(20.75)				
19.83				
17.86				
(15.6)				
14.62				
13.80*				
11.90				
(11.1)				
9.81				
9.17				
7.72				
5.69				
4.63				
3.82				

**PRZEŁOŻENIA PRZEKŁADNI
DRC01 WRAZ Z DOSTĘPNYMI
KOŁNIERZAMI PAM**

